



Intumescent gaskets for DORMA double action accessories on **ONE HOUR** timber fire doors.

Please note!

Failure to fit these gaskets according to the instructions invalidates the results of fire tests and also the CERTIFIRE approval Certificate no. CF 129.

Fitting Instructions

A
Enlarge the depth of mortise by 2 mm to accommodate the intumescent gaskets. There is no need to increase width, as the sides of the gasket do not protrude beyond the plate.
Leave the yellow backing tape in position. Remove other backing tape to expose self-adhesive faces.
Wrap gasket around component and insert into frame mortise. Secure with screws provided.

B
Enlarge the depth of mortise by 2 mm; the length by 2 mm and the width by 4 mm to accommodate the intumescent gaskets. Leave the yellow backing tape in position. Remove other backing tape to expose self-adhesive faces.
Wrap gasket around component and insert into door mortise. Secure with screws provided.
Stick the two infill pieces into the tray before hanging the door.

Mortise bottom strap into the door and secure.
Remove backing tape from gasket to expose self-adhesive face.
Place along bottom strap and press down firmly. Ensure that this is not pushed off whilst hanging door.